



COSHH essentials in brick and tile making: Silica



This information will help employers (including the self-employed) comply with the Control of Substances Hazardous to Health

Regulations 2002 (COSHH), as amended, to control exposure to respirable crystalline silica (RCS) and protect workers' health.

It is also useful for trade union safety representatives.

This sheet describes good practice using RPE and local air displacement.

It covers the points you need to follow to reduce exposure to an adequate level.

It is important to follow all the points, or use equally effective measures.

Main points

- High dust levels result from ash and brick handling.
- Breathing in dust may cause silicosis.
- Keep exposure as low as possible using all the controls in this sheet.
 Make sure the controls work.
- You need air sampling. See sheet G409.
- Health surveillance is usually needed.
 See sheet G404.

Manual dehacking and batching

Control approach R

Respiratory protective equipment (RPE)

Hazard

- Brick and tile making can produce airborne respirable crystalline silica (RCS).
- ✓ All RCS is hazardous, causing silicosis. This is a serious lung disease causing permanent disability and early death.
- ✓ Silicosis is made worse by smoking.
- √ 'Respirable' means that the dust can get to the deepest parts of the lung. Such fine dust is invisible under normal lighting.
- ✓ Keep inhalation of RCS as low as possible.
- ✓ When all controls are applied properly, less than 0.1 mg/m³ RCS is usually achievable (based on an 8-hour time-weighted average).

Crystalline silica concentrations in common materials

See table in sheet BK0.

Access and premises


- Only allow access to authorised staff.
- Provide good access to enable safe waste removal.

Equipment

- Respiratory protective equipment (RPE) is normally needed to reduce exposures to an acceptable level.
- ✓ Can you use automated systems?
- Can you de-dust bricks with compressed air in an extracted chamber?
 Or use water suppression?
- ✓ Use local air displacement see illustration. The inlet air must be clean.
- ✓ You need a downward air speed between 1 and 1.5 metres per

second around workers' breathing zones.

- Make sure that draughts do not interfere with the air flow.
- ✓ Fit a manometer or pressure gauge to show that the clean air supply is working properly.
- Fit an indicator or alarm to show if filters have blocked or failed.
- ✓ Consult HSL on new system designs. See 'Useful links'



Procedures

- Always confirm that the clean air supply is turned on and working at the start of work.
- Make sure you can get spares easily.

Maintenance, examination and testing

- Minerals and silica-containing dusts are very abrasive. Plan regular maintenance.
- ✓ Follow instructions in maintenance manuals keep equipment in effective and efficient working order.
- Clean down the equipment before starting maintenance use wet or dustless methods.
- ✓ If the filtered air supply is faulty, stop work until it is repaired.
- ✓ Daily, look for signs of damage. Make repairs.
- At least once a week, check that air filtration works properly. Check the gauge.
- ✓ You need to keep all controls in good working order. See sheet G406 for advice on engineering controls.
- ✓ You need to know the manufacturer's performance specifications to know if the equipment is working properly.
- Keep this information in your testing log-book.
- ✓ Get a competent ventilation engineer to examine the system thoroughly and test its performance at least once every 14 months. See the HSE publication HSG54 - see 'Further information'.
- ✓ Examine and test RPE thoroughly at least once every three months.
- ✓ Keep records of all examinations and tests for at least five years.
- ✓ Review records failure patterns show where preventive maintenance is needed.
- Carry out air sampling to check that the controls are working well. See sheet G409.

Personal protective equipment (PPE)

- ✓ Ask your safety equipment supplier to help you get the right PPE.
- Provide storage for clean and contaminated PPE.

Respiratory protective equipment (RPE)

- ✓ RPE is normally needed.
- ✓ RPE is often needed for maintenance and some cleaning jobs.
- ✓ Powered or air-fed RPE is more comfortable to wear.
- Select RPE that suits the wearer, the job and the work environment.
- Decide the level of protection from air sampling data. Otherwise, use RPE with an assigned protection factor (APF) of at least 10. See sheet R2.
- ✓ Disposable RPE is acceptable.
- ✓ Make sure all RPE is properly fit-tested get advice from your supplier.
- ✓ Train workers to check their RPE works properly before use.
- ✓ Replace RPE filters as recommended by the supplier. Throw away disposable RPE at the end of the job or the end of the shift.
- ✓ Keep RPE clean.

Other protective equipment

- Provide coveralls that do not retain dust. Use synthetic fabrics not cotton or knitted.
- ✓ Use a contract laundry or a suitable equivalent to wash work clothing. Warn them that the dust contains silica.
- ✓ Skin creams help in washing contamination from the skin. After-work creams help to replace skin oils.

Caution: Never allow use of compressed air for removing dust from clothing.

Health surveillance

- ✓ You need health surveillance unless exposure to RCS is well below the limit. See sheet G404.
- Consult an occupational health professional see 'Useful links'.

Cleaning and housekeeping

- Clean the machinery and workroom at least once a week.
- ✓ Use procedural controls (eg lock-off) before cleaning.
- ✓ Use a Type H vacuum cleaner fitted with a HEPA filter to clear up dust eg. on overhead fittings.

Caution: Don't clean up with a brush or compressed air.

Training and supervision

- ✓ Tell workers that silica dust can cause serious lung diseases.
- ✓ Working in the right way and using the controls correctly is important for exposure control. Train and supervise workers. See sheet BKO.

Further information

- Maintenance, examination and testing of local exhaust ventilation
 HSG54 (Second edition) HSE Books 1998 ISBN 0 7176 1485 9
- Respiratory protective equipment at work: A practical guide
 HSG53 (Third edition) HSE Books 2005 ISBN 0 7176 2904 X
- Control of respirable silica dust in heavy clay and refractory processes
 HSG72 HSE Books 1992 ISBN 0 11 885679 0
- Health surveillance: A ceramics industry booklet Leaflet IACL100 HSE Books 1996 (single copy free)
- Permit-to-work systems Leaflet INDG98(rev3) HSE Books 1997 (single copy free or priced packs of 15 ISBN 0 7176 1331 3)
- For environmental guidelines see sheet SL0

Useful links

- The British Ceramics Confederation (BCC) may advise on health and safety consultants and training providers. Website: www.ceramfed.co.uk
- For details of local air displacement controls contact the Health and Safety Laboratory (HSL) Tel: 0129 821 8000 e-mail hslinfo@hsl.gov.uk.
- For information about health and safety, or to report inconsistencies or inaccuracies in this guidance, visit www.hse.gov.uk/. You can view
 HSE guidance online and order priced publications from the website.
 HSE priced publications are also available from bookshops.
- Contact the British Occupational Hygiene Society (BOHS) on 01332 298101 or at www.bohs.org for lists of qualified hygienists who can help you.
- Look in the Yellow Pages under 'Health and safety consultants' and 'Health authorities and services' for 'occupational health'.
- Also see www.nhsplus.nhs.uk.

This document is available at: www.hse.gov.uk/pubns/guidance/ and www.hse.gov.uk/coshh/essentials/

This document contains notes on good practice which are not compulsory but which you may find helpful in considering what you need to do.

© Crown copyright If you wish to reuse this information visit www.hse.gov.uk/copyright.htm for details. First published 10/06

Employee checklist
Are you sure how to use all dust controls?
Is the equipment switched off and locked off for maintenance and cleaning?
Check your RPE works properly every time you use it.
Look for signs of leaks, wear and damage every day.
If you find any problems, tell your supervisor. Don't just carry on working.
Make suggestions to improve the effectiveness of dust control.
Co-operate with health surveillance.
Use, maintain and store your protective equipment in accordance with instructions.
Use skin creams provided as instructed.